



Creating a Wireshark Log of BACnet Activity


1. Open Wireshark and click on the network adapter you want to capture.




2. Click  to start capturing packets.



3. Enter **bacnet** as the display filter.



4. If you are debugging an issue, reproduce the problematic issue on the BACnet network.

5. Once you are confident you have all the messages you want captured, click  to stop capturing the communication.

6. Click **File->Export Specified Packets...**, change the log file format to ***.pcap**, ensure **Displayed** is selected, and save.

